""nextec-rf

<u>NB00376</u>

6.0-18.0 GHz Broad Band Amplifier

General Description

The NB00376 is a broadband power amplifier operating in 6 to 18 GHz frequency range. The model is available in a miniature housing with replaceable SMA connectors. A thin film hybrid MIC process ensures robust characteristics over operating temperature range of -30 to +70 $^{\circ}$ C. The amplifier incorporates internally protected voltage regulators and can be biased in a wide range of DC voltage. The small size, high gain and output power make the amplifier ideal for any general-purpose applications.



Performance at 25 °C

Parameter	Min.	Тур.	Max.	Units
Frequency	6.0		18.0	GHz
Gain	19	22		dB
Gain Flatness over Operating Frequency Range		± 1	± 2	dB
Noise Figure		9.0	12.0	dB
Output Power at 1 dB Compression	17	20		dBm
Saturated Output Power	20	23		dBm
Third Order Intercept Point (-10 dBm Pin, each tone)	26	29		dBm
Input VSWR		1.9:1	2.4:1	
Output VSWR		1.9:1	2.4:1	
DC Supply Voltage (Vcc+)	+11	+12	+15	V
DC Supply Voltage (Vcc-)	-15	-5	-4	V
Supplied Current at +12 V (nominal bias, -17 dBm Pin)		250	290	mA
Supplied Current at -5 V		5	8	mA

Customized Designs: For custom designs, including both electrical and mechanical, please contact us at sales@nextec-rf.com.

3350 Scott Blvd. Bldg. 49, Santa Clara, CA 95054 • Phone: (408) 727-1189 • Fax: (408) 727-5915 • <u>www.nextec-rf.com</u> April 9, 2003


₩nextec-RF

NB00376


6.0-18.0 GHz Broad Band Amplifier

Typical Test Data

Gain and Return Loss at 25 °C



Output P_{-1 dB}, IP₃ and Noise Figure at 25 ⁰C




Customized Designs: For custom designs, including both electrical and mechanical, please contact us at sales@nextec-rf.com.

3350 Scott Blvd. Bldg. 49, Santa Clara, CA 95054 • Phone: (408) 727-1189 • Fax: (408) 727-5915 • <u>www.nextec-rf.com</u> April 9, 2003



6.0-18.0 GHz Broad Band Amplifier

Outline Drawing



(unit: inch)

Biasing and Operation

- Turn off RF input power. The amplifier, being an active device, generates heat when bias is applied. Adequate heat sinking is required. Operating baseplate temperature should not exceed +70 ⁰C.
- 2. Connect ground terminal.
- 3. Apply negative supply voltage of -5 V as shown.
- 4. Apply positive supply voltage of +12 V.
- 5. Turn on RF power. The input RF power should not exceed +8 dBm.

Customized Designs: For custom designs, including both electrical and mechanical, please contact us at sales@nextec-rf.com.

3350 Scott Blvd. Bldg. 49, Santa Clara, CA 95054 • Phone: (408) 727-1189 • Fax: (408) 727-5915 • <u>www.nextec-rf.com</u> April 9, 2003